

機種[au]手帳型	機種[docomo]手帳型	機種[docomo]手帳型
FJL22 (ARROWS Z)	SH-03J (AQUOS R)	DM-01G (Disney Mobile)
HTL23 (HTC J butterfly)	SH-03K (AQUOS R2)	DM-01H (Disney Mobile)
HTV31 (HTC J butterfly3)	SH-04G (AQUOS EVER)	DM-01J (Disney Mobile)
HTV32 (HTC 10 )	SH-04H (AQUOS ZETA)	DM-01K (Disney Mobile)
HTV33 (HTC U11)	SH-05F (Disney Mobile)	DM-02H (Disney Mobile)
HWV31 (HUAWEI nova 2)	SO-01F (Xperia Z1)	F-01F (ARROWS NX)
KYL23 (miraie)	SO-01G (Xperia Z3)	F-01H (arrows Fit)
KYV31 (URBANO V01)	SO-01H (Xperia Z5)	F-01J (arrows NX)
KYV32 (BASIO)	SO-01J (Xperia XZ)	F-01K (arrows NX)
KYV33 A03 (INFOBAR)	SO-01K (Xperia XZ1)	F-02G (ARROWS NX)
KYV34 (URBANO V02)	SO-02E (Xperia Z)	F-02H (arrows NX)
KYV36 (DIGNO rafre)	SO-02F (Xperia Z1 f)	F-03H (arrows SV)
KYV37 (Qua phone)	SO-02G (Xperia Z3 Compact)	F-03K (らくらくスマートフォンme)
KYV38 (URBANO V03)	SO-02H (XPERIA Z5 compact)	F-04G (ARROWS NX)
KYV39 (miraie f)	SO-02J (Xperia X Compact)	F-04J (らくらくスマートフォン4)
KYV40 (rafre)	SO-02K (Xperia XZ1 Compact)	F-04K (arrows Be)
KYV42 (Qua phone QX)	SO-03F (Xperia Z2)	F-05J (arrows Be)
KYV44 (Qua phone QZ)	SO-03G (Xperia Z4)	F-06F (らくらくスマートフォン3)
KYY21 (URBANO L01)	SO-03H (XPERIA Z5 Premium)	L-01J (V20 PRO)
KYY22 (URBANO L02)	SO-03J (Xperia XZs)	L-01K (V30+)
KYY23 (URBANO L03)	SO-03K (Xperia XZ2)	L-02K (JOJO)
LGL22 (isai)	SO-04E (Xperia A)	LG-H798(Nexus5X)*
LGL24 (isai FL)	SO-04F (Xperia A2)	MO-01J (MONO)
LGV31 (isai VL)	SO-04G (Xperia A4)	SC-01F (GALAXY Note 3)
LGV32 (isai vivid レザー非対応)	SO-04H (Xperia X Performance)	SC-01G (GALAXY Note Edge)
LGV33 (Qua phone PX)	SO-04J (Xperia XZ premium)	SC-01K (Galaxy Note8)
LGV34 (isai Beat)	SO-05K (Xperia XZ2 Compact)	SC-02F (GALAXY J)
LGV35 (isai V30+)		SC-02G (GALAXY S5 ACTIVE)
SCL22 (GALAXY Note 3)		SC-02H (Galaxy S7 edge)
SCL24 (GALAXY Note Edge)		SC-02J (Galaxy S8)
SCV31 (Galaxy S6 edge)		SC-02K (Galaxy S9)
SCV32 (Galaxy A8)	<b>機種[au]手帳型</b>	SC-03J (GALAXY S8 PLUS)
SCV33 (Galaxy S7 edge)	SHV38 (AQUOS SERIE mini)	SC-03K (Galaxy S9+)
SCV35 (GALAXY S8 PLUS)	SHV39 (AQUOS R)	SC-04E (GALAXY S4)
SCV36 (Galaxy S8)	SHV40 (AQUOS sense)	SC-04G (Galaxy S6 edge)
SCV37 (Galaxy Note8)	SHV41 (AQUOS R compact)	SC-04J (Galaxy feel)
SCV38 (Galaxy S9)	SHV42 (AQUOS R2)	SC-05G (GALAXY S6)
SCV39 (Galaxy S9+)	SOL22 (Xperia UL)	SH-01F (AQUOS PHONE ZETA)
SHL22 (AQUOS PHONE SERIE)	SOL23 (Xperia Z1)	SH-01G (AQUOS ZETA)
SHL23 (AQUOS PHONE SERIE)	SOL25 (Xperia ZL2)	SH-01H (AQUOS ZETA)
SHL24 (AQUOS PHONE SERIE mini)	SOL26 (Xperia Z3)	SH-01K (AQUOS sense)
SHL25 (AQUOS PHONE SERIE)	SOV31 (Xperia Z4)	SH-02F (AQUOS PHONE EX)
SHV31 (AQUOS SERIE mini)	SOV32 (Xperia Z5)	SH-02G (Disney Mobile)
SHV32 (AQUOS SERIE)	SOV33 (Xperia X Performance)	SH-02H (AQUOS compact)
SHV33 (AQUOS SERIE mini)	SOV34 (Xperia XZ)	SH-02J (AQUOS EVER)
SHV34 (AQUOS SERIE)	SOV35 (Xperia XZs)	SH-03G (AQUOS ZETA)
SHV35 (AQUOS U)	SOV36 (Xperia XZ1)	
SHV37 (AQUOS U)	SOV37 (Xperia XZ2)	<b>生産終了モデル</b>
		<b>SC04F/SH02E/SCL23/KYL22</b>

機種[SoftBank]手帳型	機種[その他]手帳型	機種[その他]手帳型
204SH (シンプルスマホ)	507SH (Android One)	freetel XM
302SH (AQUOS PHONE Xx)	Android One S1	FTJ152C-MIYABI
303SH (AQUOS PHONE Xx mini)	Android One S2	FTJ152F-KATANA 02
304SH (AQUOS Xx)	Android One S3 (S3-SH)	FTJ161B-REI
305SH (AQUOS CRYSTAL)	Android One S4	FTJ162D-Priori4
401SH (シンプルスマホ2)	Android One X1	FTJ162E-RAIJIN
401SO (Xperia Z3)	Android One X2	FTJ17C00-Priori5
402SH (AQUOS CRYSTAL X)	Android One X3	LG-D821(Nexus5)*
402SO (Xperia Z4)	402SH (AQUOS CRYSTAL Y)	LG-H798(Nexus5X)*
403SH (AQUOS CRYSTAL 2)	403SH (AQUOS CRYSTAL Y2)	XT1100(Nexus6)*
404KC(DIGNO U)*	404SH (AQUOS Xx-Y)	H1512(Nexus6P)*
404SC(Galaxy S6 edge)*	SHV37(AQUOS L)*	D626X(HTC Desire 626)*
404SH (AQUOS Xx)	SH-L02(AQUOS L2)*	M910(HTC Desire EYE)*
501SO (Xperia Z5)	SHV40(AQUOS sense)	503HW (LUMIERE)
502SH (AQUOS Xx2)	SH-M02(g04)*	MT-J1(Ascend Mate7)*
502SO (Xperia X Performance)	SH-M01 (AQUOS)	honor 8 (HUAWEI)
503KC (DIGNO F)	SH-M02 (AQUOS)	honor6 Plus (HUAWEI)
503SH (AQUOS XX2 mini)	SH-M03 (AQUOS mini)	Mate 9 (HUAWEI )
506SH (AQUOS Xx3)	SH-M04 (AQUOS)	Mate S (Huawei)
509SH (シンプルスマホ3)	SH-M05 (AQUOS sense lite)	nova (HUAWEI)
601HT (HTC U11)	SH-M06 (AQUOS R compact)	nova 2 (HUAWEI)
601SO (Xperia XZ)	SH-RM02 (AQUOS)	PRA-LX2/nova lite (HUAWEI)*
602KC (DIGNO G)	ARROWS M01	nova lite 2 (HUAWEI)
602SO (Xperia XZs)	RM02(arrows M02)*	VTR-L09/P10 (HUAWEI)*
603SH(AQUOS Xx3 mini)*	RM03(arrows M03)*	WAS-LX2J/P10 lite (HUAWEI)*
605SH (AQUOS R)	arrows M04	P10 Plus (HUAWEI)
606SH (AQUOS ea)	arrows M04 PREMIUM	ALE-L02/P8lite (HUAWEI)*
701SH (AQUOS R compact)	RM02(arrows RM02)*	EVA-L09 L19 L29/P9 (HUAWEI)*
701SO (Xperia XZ1)	T00P A500KL (ZenFone 5)	VNS-L22/P9lite (HUAWEI)*
801SO (Xperia XZ2)	X013DB ZB551KL (Zenfone GO)	SCL-L02/Y6 (HUAWEI)*
H1512(Nexus6P)*	X008D ZC520TL (ZenFone 3 Max)	Moto G5 (Motorola)
nova lite 2 (HUAWEI)	Z01BDA/B/C ZC551KL (ZenFone 3 Laser)	Moto G5 Plus (Motorola)
	X00DD/A/B ZC553KL (ZenFone 3 Max)	TONE m15
	Z00UD ZD551KL (ZenFone Selfie)	TONE m17
	ZD552KL (ZenFone 4 Selfie Pro)	D5788(Xperia J1 Compact)*
	Z00ED ZE500KL (ZenFone 2 Laser)	AXON mini (ZTE)
	Z017DA ZE520KL (ZenFone 3)	Blade Vec 4G (ZTE)
	Z00AD ZE551ML (ZenFone 2)	302HW (STREAM S)
	Z012DE ZE552KL (ZenFone 3)	402LG (Spray)
	Z01KD_1/Z01KD_2 ZE554KL (ZenFone 4)	KC-01
	Z01FD ZS550KL (ZenFone 3 Deluxe)	KCP01K (LUCÉ)
	Z01GD ZS551KL (ZenFone 4 Pro)	S301 (KYOCERA)
	Z016D ZS570KL (ZenFone 3 Deluxe)	
	A002A ZS571KL (ZenFone AR)	
		スライド S サイズ
		スライド M サイズ
		スライド L サイズ